This manual is for reference and historical purposes, all rights reserved.

This page is copyright© by M. Butkus, NJ.

This page may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

This is the full text and images from the manual. This may take 3 full minutes for the PDF file to download.

If you find this manual useful, how about a donation of \$3 to: M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701 and send your e-mail address so I can thank you. Most other places would charge you \$7.50 for a electronic copy or \$18.00 for a hard to read Xerox copy.

This will allow me to continue to buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

If you use Pay Pal or wish to use your credit card,

click on the secure site on my main page.

SEKONIC SYSTEM METER

INSTRUCTION BOOK model L-428





SEKONIC

Contents

reactives of the SENOIVIC System Meter	
Specifications	4
Names of Parts	6
Preparation	8
1. Zero Check and Adjustment	8
2. Inserting Batteries	9
3. Battery Check ·····	10
Employing Standard Accessories	11
Incident Light Measurement	12
1. Installing Lumisphere on Light Sensor	12
2. Setting Film Sensitivity	12
3. Selecting H or L Range	13
4. Measurement & Exposure Reading	13
Intermediate Shutter Scale Indications	15
Intermediate f/number Scale Indications	15
Switch Button Lock	15
5. Exposure Value (EV Reading)	16
Reflected Light Measurement	18
Contrast Measurement	20
Illuminance Measurement (lux)	21
Special Accessories (Separately Sold)	22
Handling Cautions	23
Memo	24

FEATURES OF THE SEKONIC SYSTEM METER

1. High Accuracy

- * Silicon light sensing diode is employed as the light sensor element.

 Response is fast under both low and high illumination.
- * Stability and accuracy are advanced to a new level

2. Easy to Employ

- Switchable H and L range scales are evenly graduated for easy reading at any position.
- ★ Wide measuring range from EV-3 to +18.
- ★ Freely rotating light sensor section. Rotation angle Right: 200° Left: 100°
- Meter pointer can be stopped at the deflected position (meter stop mechanism).
- * Switch lock mechanism can be employed in either ON (light measurement) or OFF (pointer stop & storage) positions.

3. Reliability

* Internal circuitry utilizes high reliability electronic components and printed circuit module. Stable performance is maintained over long term usage.

4. Full Selection of Accessories

- A complete range of accessories is available to make this a system meter with flexibility to meet intended applications.
- Standard Accessories
 Lumisphere, Lumidisc, Reflected Light Filter

- ★ Special Accessories (Sold Separately)
 - Viewfinder (10° light receiving angle attachment)
 - Enlarger Attachment (for enlarger exposure measurements)
 - Pinpoint Attachment (for measuring light distribution on view camera focal plane)
 - Microscope Attachment (for exposure measurements in photomicroscopy)
 - Special Dials for Each Attachment
 - Movie Dial (exposure and computing dial for movie photography)



SYSTEM METER COMPOSITION



Viewfinder (w/special dial)

Enlarger Attachment (w/special dial)



Pinpoint Attachment (w/special dial)







Microscope Attachment (w/special dial)



SPECIFICATIONS

Measuring System

Incident & reflected light

(interchangeable dials & attachments available

according to application)

H & L 2-step switchable linear scale

Measuring Range

Incident light (w/Lumisphere):

L Range = EV $-3 \sim +8$ (ASA100) H Range = EV +8 \sim 18 (ASA100)

Reflected light (w/reflected light filter):

L Range = EV +1 \sim 12 (ASA100)

H Range = EV 12 ~ 22 (ASA100)

Accuracy

Scales

Within ±%EV

Light Sensor Section

Incident light: Lumisphere & Lumidisc

Reflected light: reflected light filter (40° light receiving

angle), Viewfinder (10° light receiving

angle) and various attachments Element:

silicon photodiode, sensitivity

compensation by filter

 $ASA = 0.8 \sim 25,000$

 $DIN = 0 \sim 45$ $f/stop = 1 \sim 90$

Exposure time = 1/4000 sec ~ 60 min

EV = -7 ~ +24

Power Source 4 mercury batteries JIS #G13 (1.5V)

Electronic Circuitry All-transistorized

Calibration Factor C = 340 K = 12.5

Dimensions $136 \times 65 \times 47$ mm

Standard Accessories

Weight Approx. 280g (incl. batteries)

Others Battery checker mechanism

Pointer lock mechanism
Switch button lock mechanism

Special Accessories Viewfinder, Enlarger Attachment, Pinpoint Attachment, Microscope Attachment, various special dials, and Movie

Lumisphere, Lumidisc, reflected light filter, strap

Dial

NAMES OF PARTS






PREPARATION



Confirm zero position before using.



Remove batteries and depress switch button.



Take out dial mounting screw and remove dial. Adjust by turning zero adjusting screw.

1. ZERO CHECK AND ADJUST-MENT

Before performing measurements, confirm that the meter pointer (6) properly indicates the zero mark (9).

Confirmation

- * Remove batteries and depress switch button 4 to release the meter lock. The pointer will deflect toward the left and should indicate the zero mark 9.
- * If the pointer deviates from the zero mark, perform adjustment.

Adjustment

- * With fingertips, turn the dial mounting screw (8) counter-clockwise and remove the dial.
- * While switch button 4 is depressed, gently turn the zero adjusting screw with a screwdriver to align the pointer with the zero mark 9.

NOTE

- Be sure to remove batteries before confirming zero position.
- See next page for battery cover opening instructions.

2. INSERTING BATTERIES


Four JIS #G13 (1.5V) mercury cells are employed for power. (Equivalent are Mallory MS-76H, Eveready S-76E, Ray-O-Vac RS76G)

- * Use a coin etc. to turn the battery cover lock screw (24) toward the O (Open) direction.
- * When lock screw disengages, gently raise the battery cover (23) to open it
- * After observing battery polarities (+ & -) and the polarity markings of the battery compartment, insert two batteries into each receptacle. Both batteries in each receptacle should be faced the same way.
- * Replace the battery cover 23, press lightly with fingertips and turn the lock screw toward C (Close) to secure.

NOTE

- ★ Use caution when inserting batteries not to reverse (+ & -) polarities.
- * To prevent inadvertent switch closing from draining battery power when not in use, make it a habit to lock the switch button 4 in the OFF position.
- When not using the meter for an extended period (more than a month), remove batteries and store in a dry place.










3. BATTERY CHECK

If the batteries have declined below their rated voltage, correct readings will not be obtained. Check the battery voltage before using.

- ★ Leave switch button ④ in the OFF position.
- * Depress battery check button 22 on rear of meter.
- * Pointer should indicate the red battery check mark (5). If it does not reach the mark, replace batteries.

EMPLOYING STANDARD ACCESSORIES

INCIDENT LIGHT MEASUREMENT



USE LUMISPHERE TO ME-ASURE INCIDENT LIGHT

1. INSTALL LUMISPHERE ON LIGHT SENSOR

Align the white dot of the Lumisphere interior with the white dot of the light sensor mounting flange. Gently turn the Lumisphere clockwise to secure it.



2. SETTING FILM SENSITIVITY

Set the sensitivity value of the employed film. Use the right side scale (6) for setting ASA, and the left side scale (7) for DIN.

- * With the fingertips, turn the film sensitivity knob (4) to set the proper value in the scale window.
- * ASA 100 and DIN 21 setting is shown in the photo.
- Intermediate film sensitivities are as shown in the table.



3. SELECTING H OR L RANGE

H (high) and L (low) illumination measurements can be performed by simply sliding the H-L selector knob (1). The knob is coupled with the light scale (7), which also changes to display the appropriate range.

NOTE

- * Perform initial measurement at the H range.
- If the pointer deflects completely toward the left, switch to the L range and perform measurement.

4. MEASUREMENT & EXPO-SURE READING

- a) From the location of the subject desired to be measured, point the Lumisphere toward the camera. (The light sensor section can be freely rotated.)
- b) Hold the exposure meter properly and depress the switch button (4). The pointer will deflect according to the brightness. When the switch button is released, the pointer will hold at the deflected position.









- c) Read value of scale indicated by the pointer.
- d) Transfer the value to the dial light scale (13). Turn the dial ring and align the value with the incident light indicator .
- e) At this time, the f/number scale (19) and shutter scale (20) combination becomes the proper exposure.

NOTE

With ASA100, if the pointer indicates 10 on the light scale, the proper exposure becomes 1/8sec at f/2.8, 4sec at f/16, 2min at f/90, etc.



Shutter scale indications 20



- ★ White numeral indication 1/sec . . . /60 is 1/60sec m (minutes) . . . 30m is 30 minutes
- Red numeral indication S (sec) . . . 15s is 15 seconds
- Intermediate scales become as shown in the table.

Intermediate Shutter Scale Indications



Intermediate f/number Scale Indications (19)

 Intermediate values indicated by the small white dots are as shown in the table below.




SWITCH BUTTON LOCK

The switch button (4) is provided with a convenient locking mechanism. It can be locked at either the ON or OFF position.

a) Lock at OFF position

- Prevents inadvertent depressing of the switch button during transportation and storage from causing unnecessary battery drain.
- * With the switch button 4 in the OFF position, turn the lock lever 3 toward the L mark.






b) Lock at ON Position

- Convenient when performing measurements without pointer being stopped.
- * With the switch button (4) in the depressed position, turn the lock lever (3) toward L.
- * Switch button remains locked when finger is lifted from button.
- Since extended use causes battery drain, employ this feature only when necessary.

c) Releasing lock lever

- * Turn lock lever 3 in direction opposite L. Lock will be released.
- If locked in the ON position, the switch will become OFF as the lock is released.




5. EXPOSURE VALUE (EV READING)

When employing a light value system shutter and f/stop combination camera, it is convenient to set by reading this exposure value.

a) Read light scale value indicated by the pointer.


b) Transfer the value to the dial light scale (3). Turn the dial ring and set value to the incident light indicator mark (2). (During reflected light measurement, set to reflected light indicator mark (5)).



The value indicated on the EV scale
 by the arrow becomes the proper exposure value.



REFLECTED LIGHT MEASUREMENT



USE REFLECTED LIGHT FILTER TO MEASURE REFLECTED LIGHT

1. INSTALLING REFLECTED LIGHT FILTER TO LIGHT SENSOR SECTION

The reflected light filter is employed when measuring the light reflected from the subject (illumination). In addition to determining subject contrast, it can also be employed when incident light measurements are difficult to perform.

- * Install the reflected light filter in the same manner as the Lumisphere.
- * Remove the Lumisphere by turning it counter-clockwise.
- Align the reflected light filter with the light sensor positioning mark and turn it clockwise to secure.



2. FILM SENSITIVITY SETTING

* Setting is the same as for incident light measurement. See Page 12.

3. H-L RANGE SELECTION

 Same as for incident light measurement. See Page 13.

4. MEASUREMENT & EXPO-SURE READING

- a) Point the reflected light filter towards the desired location of the subject to be measured. (Light sensor section rotates freely.)
- b) Measure as close to the subject as possible and take readings from important subject areas. Use adequate care at this time not to induce the exposure meter shadow etc. into the area to be measured.
- c) Depress the switch button (4) and read the value indicated by the pointer.
- d) Transfer the value to the dial light scale (3). Turn the dial ring and align the value with the reflected light indicator mark (6).
- e) The f/stop scale (9) and shutter scale (20) combination at this time is for proper exposure.


NOTE

- ★ Use caution not to misinterpret the incident light indicator mark (1) for the reflected light indicator mark (1).
- A standard reflectance hand-screen (sold separately) can be employed during reflected light measurement to provide the correct value.



CONTRAST MEASUREMENT





Contrast ratio according to light scale value difference is as indicated in the table.

Light scale difference	Contrast ratio
1	2:1
1½	3:1
2	4:1
3	8:1
4	16:1
5	32:1

USE LUMIDISC TO MEASURE CONTRAST

1. INSTALL LUMIDISC TO LIGHT SENSOR

The illumination contrast between the main light and fill-in light contrast can be measured to control the illumination.

- * Install the Lumidisc in the same manner as the Lumisphere.
- * Turn counter-clockwise to remove, and clockwise to install.

2. MEASUREMENT & CONTRAST READING

- a) Hold the exposure meter at the subject position and point the Lumidisc correctly toward the center of the main light source.
- b) Depress the switch button 4 and read the value indicated by the pointer.
- c) In the same manner, read the value of the fill-in light source. Take care not to allow the main light source to interfere with the measurement. Point the Lumidisc toward the center of the fill-in light source.
- d) Obtain the difference between the main and fill-in light sources. If the difference is 1, for example, the contrast ratio becomes 2 : 1.
- e) To determine exposure, install the Lumisphere and measure by general incident light method.

ILLUMINANCE MEASUREMENT (LUX)

1. INSTALL LUMIDISC TO LIGHT SENSOR

By employing the Lumidisc, the instrument can be used as an illumination meter

* Install Lumidisc to light sensor in same manner as Lumisphere.

2. MEASUREMENT & READ-

- a) Place so that Lumidisc is parallel with surface to be measured.
- b) Depress switch button (4), pointer will deflect according to the brightness. At the stopped position, release the switch button and the pointer will hold at the deflected position.
- If the pointer deflects completely toward the left, switch to the L scale with the H-L knob.
- d) Read the light scale value indicated by the pointer and determine the illumination (lux) from the table.
- e) To determine intermediate values, multiply by the following factors:

+1/3. . . .1.26 +1/2. . . .1.41 +2/3. . . .1.59

EXAMPLE:

 Assume a light scale indication of 9-1/3. The illumination for 9 according to the table is 110. Multiply 110 by the +1/3 factor, 1.26.
 Thus:

110x1.26=138.6 lux

In the same manner: 9-1/2 becomes 155 lux and:

9-2/3 becomes 175 lux



Light scale	Lux	Light scale	Lux
1	0.42	12	880
2	0.85	13	1,750
3	1.7	14	3,500
4	3.4	15	7,000
5	7	16	14,000
6	14	17	28,000
7	28	18	56,000
8	55	19	112,000
9	110	20	224,000
10	220	21	448,000
11	440	22	895,000

SPECIAL ACCESSORIES (SEPARATELY SOLD)



The following special accessories are available to compose the System Meter. A detailed instruction book is included in each separate set.

1. Movie dial

Employed when performing movie photography.

2. Viewinder with special dial

Employed when measuring reflected light at the camera position or closeup subject. Light receiving angle is 10° and since the actual measured portion can be confirmed by eye, accurate exposure measurements can be performed.

3. Enlarger attachment with special dial

Employed for measuring exposure in enlarging.

4. Pinpoint attachment with special dial

Employed for measuring light distribution on view camera focal plane.

Microscope attachment with special dial

For exposure measurements in photomicroscopy.

HANDLING CAUTIONS

Since the System Meter L-428 is a precision instrument, caution is recommended concerning the following points.

- a) Avoid dropping or applying strong shock to the Meter.
- b) Do not store in locations with high temperature or humidity.
- c) Avoid storing in locations with magnetic fields or where insecticides have been used (metal cabinets, dressers, etc.)
- d) Avoid scratching the Lumisphere and Lumidisc, and always keep them clean. (When soiled, they can be washed thoroughly in a lukewarm soap and water solution.)

In event of malfunction, bring or send the Meter to the nearest SEKONIC sales office or Authorized Service Station.

If necessary to ship the Meter to a Service Station, be sure to wrap in shock-absorbing material at least 3cm (1-1/4 in) thick, then pack in a strong corrugated box.